



UNIVERSITY OF  
**ILLINOIS**  
URBANA - CHAMPAIGN

**ME 330: Engineering Materials**




Lab - 9

# Polymer and Composite Tensile Testing




**Grainger College  
of Engineering**

UNIVERSITY OF ILLINOIS URBANA-CHAMPAIGN




# Map of Composite Materials




# Fiber Reinforcement Influences


## Concentration




## Size




## Shape



## Distribution




## Orientation




# Rule of Mixtures



## Tungsten (fiber) in Copper(matrix)




# Rule of Mixtures



$$k = \frac{F}{\delta} = \frac{\sigma A_0}{\varepsilon L_0} = E \left( \frac{A_0}{L_0} \right)$$





# Deforming Semi-Crystalline Polymers





Due to low melting temperatures, stress relaxation and creep are important at room temperatures.

Relaxation modulus:



Creep modulus:




$$E_r(t) = \frac{\sigma(t)}{\epsilon}$$

$$E_r(t) \neq E_c(t)$$

$$E_c(t) = \frac{\sigma}{\epsilon(t)}$$


# Material Models

Solids




$$\sigma = E\varepsilon$$

Viscoelastic  
solids




$$\sigma = E\varepsilon + \eta\dot{\varepsilon}$$

Viscoelastic  
liquids



$$\dot{\varepsilon} = \frac{\sigma}{\eta} - \frac{\dot{\sigma}}{E}$$

Liquids



$$\sigma = \eta\dot{\varepsilon}$$

